



newsuperantenna.com

APPLICATION NOTE

Using the Super Antenna MP1 on the HF bands 40 meters through 10 meters

Connect the supplied 40m - 10 meter radial set
MR4010 SuperWire Radial Set
to the radial connection terminal of the mount.

Hold the FG1 Frequency Guide on the
LEFT Side of the SuperSlider

Adjust the bottom edge of the
SuperSlider sliding metal tube
to match the desired frequency
using the BLACK frequency scale.

Line up the BLACK arrow
NOTCH of the FG1 Frequency Guide
under the bottom metal ring of the
SuperSlider Coil.

*** Caution: DO NOT TIGHTEN
the Thumb Screw for base or
portable operation. You can
gently tighten it for mobile
operation in motion.**

Example A:
Shows the antenna
set to 14 MHz in the
20 meter band

